



Part No.	Part Name
84043	BRASS ROLLER LINE GUIDE
84045	STEEL BAIL WIRE SCREW
84048	STEEL BAILSPIRING COVER
84049	STEEL BAIL SPRING
84053	COVER (BRACKET SIDE)
84054	BAIL RELEASE LEVER
84055	BAIL TRIP LEVER SPRING
84064	STEEL SPLIT PIN
84073	STEEL DRAG SPRING
84074	DRAG SPRING CASING
84075	DRAG SPRING CASING RETAINER
84076	STEEL DRAG BUTTON INDEX
84077	DRAG ADJUSTING KNOB
84080	CLICK SPRING WASHER
84084	ANTI-REVERSE FRICTION
84088	OSCILLATION SLIDE SCREW
84095	SPOOL—STANDARD GRAPHITE
84096	STEEL AXLE
84100	ANTI-REV.RATCHET(SET2)
84104	BRONZE ANTI-REVERSE LEVER
84105	HANDLE SCREW
84107	STEEL CLICK SPRING.
84108	STEEL ANTI-REVERSE CLICK
84110	TRANSLATION SLIDE
84111	STEEL OSCILLATION ARM
84114	HANDLE COMPLETE
84123	DRAG ASSEMBLY

Part No.	Part Name
84126	BRASS ROLLER RACE
84291	BAIL ARM
84293	STEEL BAIL ARM SCREW
84294	SCREW/BAILARM COVER & BRKT
84297	STEEL BAIL WIRE
84299	ROTATING HEAD HEX NUT
84515	BUSHING
84598	GRAPHITE ROTATING HEAD
84603	RELEASE LEVER SCREW
84604	STEEL COVER SCREW
84609	ANTI-REVERSE BUTTON
84610	STEEL DRAG KNOB SCREW
84611	STEEL CLICKSPRING SCREW
84612	STEEL ANTI-REVERSE SCREW
84618	PINION KIT SCREW
84626	DRIVE GEAR
84627	BRONZE PINION
84628	GRAPHITE COVER
84629	GRAPHITE HOUSING
84630	BRASS PINION SPACER
84632	BUSHING
84787	STEEL HEX NUT SCREW
84789	BRASS ROTATING HEAD WASHER
84871	ADJ. WASHERS FOR MAIN GEAR
84873	BUSHING PLATE
84876	SLEEVE