



Part No.	Description
8311400	LOCK WASHER
8501900	OSCILLATION SLIDE CLIP SCREW
8502300	ANTI-REVERSE BUTTON
8503300	HANDLE WASHER
8503400	BAIL ARM
8503500	BAIL ARM WASHER
8503600	LINE GUIDE
8503800	LINE GUIDE SCREW
8503900	HEX NUT LOCKING RING
8504500	BAIL ARM SCREW
8504600	BAIL SPRING
8504700	BAIL SPRING RETAINER
8505100	DRAG COUNTER TAPE
8505300	ANTI-REVERSE SPRING
8505400	RETAINER SCREW
8505500	BALL BEARING
8505600	DRIVE GEAR SHIM
8505800	DRAG CLICK SPRING
8505900	MOUNTING SCREW
8506500	DRAG WASHER RETAINER
8506600	DRAG HUB
8506700	WASHER
8506800	RETAINER CLIP
8506900	DRAG KNOB
8507000	DRAG KNOB SCREW
8507100	DRAG CLICK
8507200	DRAG CLICK SPRING
8507300	DRAG KNOB COVER
8507400	DRAG COVER
8507500	DRAG COUNTER WINDOW
8507600	HANDLE CAP SCREW
8507900	SIDE PLATE SCREW
8508300	CAP SCREW WASHER
8508800	HANDLE KNOB SCREW
8509200	HANDLE KNOB

Part No.	Description
8509300	HANDLE KNOB COVER
8509900	BUSHING
8510900	DRAG COVER SCREW
8513300	DRIVE GEAR
8513400	PINION GEAR
8513500	CROSS WIND GEAR
8513600	OSCILLATION SLIDE
8513700	OSCILLATION SLIDE CLIP
8513800	CROSS WIND GEAR BUSHING
8513900	BEARING RETAINER
8514000	BRONZE BUSHING
8514100	ANTI-REVERSE DOG
8514200	ANTI-REVERSE FRICTION
8514400	ROTATING HEAD
8514500	ANTI-REVERSE SHAFT
8514800	AXEL ASSEMBLY
8514900	BAIL SPRING PIN
8515000	TRIP LEVER
8515100	HEX NUT
8515200	BAIL SPRING COVER
8515600	BAIL WIRE ASSEMBLY
8516300	FRICTION SPRING RETAINER
8516500	HANDLE ARM
8516600	HANDLE
8516700	O RING
8516800	O RING
8516900	WASHER
8517800	WASHER
8518100	COUNTERWEIGHT
8518200	DRAG ASSEMBLY
8532600	SPOOL
8553000	BAIL ASSEMBLY KIT
8589400	HOUSING
8589600	SIDE PLATE