


V-3302/331A10-C.02 85



Part No.	Part Name
81001	DRAG ADJUSTING KNOB
81002	STEEL BRAKE SPRING
81003	TEFLON DRAG WASHER
81005	STEEL CLICK SPRING
81006	SPINDLE
81008	STEEL HEX NUT
81012	SHIMS/ADJ HEAD & DR GEAR
81024	BRASS ADJUSTMENT SHIMS
81027	LUBE PORT SCREW
81028	OSCILLATION GUIDE SCREW
81029	OSCILLATION GUIDE
81030	OSCILLATION SLIDE
81031	PIVOT GEAR
81032	TRANSFER GEAR
81039	BRASS COVER SCREW
81044	HANDLE KNOB SCREW
81047	SHIMS/ADJUST. PINION GEAR
81061	STEEL AXLE
81063	BAFFLE PLATE
81064	BRASS BAIL PIVOT SCREW
81065	STEEL TRIP LEVER SPRING
81066	BRASS BAIL MOUNT SCREW
81068	TRIP LEVER & SPRING
81069	STEEL STEEL TRIP LEVER
81071	BRONZE BAIL LOCK SPRING
81072	BRASS BAIL LOCK SCREW
81073	BRASS BAIL LOCK BUTTON
81074	BAIL & HANDLE BUSHING
81079	LEAD COUNTERWEIGHT
81080	COUNTERWEIGHT SCREW

Part No.	Part Name
81081	STEEL BAIL SPRING
81082	STEEL KEYED WASHER
81091	SPOOL ARBOR
81107	COVER PLATE BEARING
81827	SPOOL—SHALLOW GRAPHITE
81945	ANTI-REV. DCG
82134	FIBRE WASHER
82572	BRASS ROLLER LINE GUIDE
82576	COVER PLATE SEAL
82518	ZINC ALLOY PINION GEAR
82527	HANDLE COMPLETE
82950	HANDLE KNOB
83014	BAILWIRE BRACKET
83015	BRASS BAILWIRE
83017	BAILWIRE BRACKET SCREW
83052	BRASS SHIMS/ADJ TRIP LVR
83442	TRANSFER GEAR
83443	ANTI-REVERSE CLICK
83446	BRASS TRANSF. GR. SPACER
83447	STEEL DRIVE GEAR
83470	ALUMINUM ALLOY HOUSING
83472	ALUM.ALLOY COVER PLATE
83474	BRASS BAIL WIRE MOUNT
83476	PUSH BUTTON
83477	BRASS BAIL WIRE SCREW
83478	ALUM.ALLOY ROTAT. HEAD
83587	LEATHER DRAG WASHER
83666	SPOOL—DEEP METAL
83585	ROTATING HEAD WASHER