



Part No. Description

8505500	BALL BEARING
8507600	HANDLE CAP SCREW W/ WASHER
8508300	CAP SCREW WASHER
8633100	COVER PLATE N1
8640000	HOUSING
8640100	SIDE PLATE
8640600	ANTI-REVERSE BUTTON
8640800	ROTATING HEAD
8641100	DRAG KNOB
8641200	DRAG RETAINER
8641300	KEYED DRAG WASHER
8641400	DRAG WASHER
8641500	EARED DRAG WASHER
8641600	BASE DRAG WASHER
8641700	CLICK GEAR
8641800	AXLE
8641900	BAIL ARM
8642000	BAIL RETAINING PIN
8642100	RETAINING PIN CLIP
8642200	LINE GUIDE SCREW
8642300	LINE GUIDE RACE
8642400	LINE GUIDE
8642500	BAIL WIRE W/ MOUNT
8642700	COVER PLATE SCREW
8642800	BAIL SPRING
8642900	TRIP LEVER
8643000	TRIP LEVER SPRING

Part No. Description

8643100	TRIP LEVER SPRING PIN
8643200	TRIP LEVER SCREW W/ BUSHING
8643300	KEYED WASHER
8643400	ROTATING HEAD NUT
8643500	KEYED SPACER WASHER
8643600	PINION GEAR W/ RATCHET
8643700	BEARING RETAINER
8643800	BEARING RETAINER SCREW
8643900	ANTI-REVERSE DOG
8644000	AR DOG SCREW W/ BUSHING
8644100	ANTI-REVERSE LEVER
8644200	HOUSING BUSHING
8644300	SIDE PLATE BUSHING
8644500	ANTI-REVERSE FRICTION SPRING
8644700	SIDE PLATE SCREW
8644800	HANDLE
8644900	SPOOL
8645300	AXLE W/ CLICK GEAR
8646600	SPOOL CLICK
8646700	SPOOL CLICK SPRING
8646800	SPOOL CLICK SCREW
8647100	SHIM - DRIVE GEAR
8647400	CROSS WIND GEAR
8647500	OSCILLATION SLIDE
8647600	OSCILLATION SLIDE SCREW
8647700	DRIVE GEAR