



Part No.	Description
8429300	BAIL ARM SCREW
8429900	ROTATING HEAD HEX NUT
8502000	CROSS WIND BUSHING
8502700	LINE CLIP
8502800	RETAINING CLIP
8503300	HANDLE KNOB WASHER
8503600	LINE GUIDE
8503800	LINE GUIDE SCREW
8503900	HEX NUT LOCKING RING
8504600	BAIL SPRING
8504800	BAIL SPRING PIN
8505300	ANTI-REVERSE SHAFT SPRING
8505500	BALL BEARING
8505600	SHIM - DRIVE GEAR
8505900	MOUNTING SCREW
8507600	HANDLE CAP SCREW W/ WASHER
8508300	CAP SCREW WASHER
8508800	HANDLE KNOB SCREW
8549800	HANDLE KNOB
8590300	DRIVE GEAR
8590400	PINION GEAR
8590500	CROSS WIND GEAR
8590600	OSCILLATION BLIDE
8590700	OSCILLATION BLIDE SCREW
8590800	BEARING RETAINER
8591200	ANTI-REVERSE SHAFT
8591300	AXLE
8592000	TRIP LEVER

Part No.	Description
8592100	ANTI-REVERSE FRICTION
8592600	SPOOL CLICK
8592700	SPOOL SPINDLE
8593000	EARED DRAG WASHER
8593100	KEYED DRAG WASHER
8593200	DRAG WASHER
8593300	DRAG RETAINER
8593900	BASE DRAG WASHER
8594400	ANTI-REVERSE DOG
8594500	HOUSING BUSHING
8595700	SIDE PLATE SCREW
8595800	HANDLE
8596000	RETAINING SCREW
8596800	ANTI-REVERSE BUTTON
8596900	DRAG KNOB
8597000	HANDLE ARM
8597100	BAIL ARM
8597300	COVER PLATE N1
8597400	BAIL WIRE W/ COVER PLATE
8597500	ROTATING HEAD
8597700	BEARING WASHER
8602500	SIDE PLATE
8602600	HOUSING
8602700	SPOOL
8611500	AR FRICTION BUSHING
8611600	AR FRICTION WASHER
8792200	LINE GUIDE RACE