



KEY NO.	PART NO.	DESCRIPTION
1	001N045	Right Side Plate
2	002 025	Quadrant Ring
3	003N025	Dog Bridge (2 req.)
4	004 025	Gear Stud Washer
5	005P025	Main Gear
6	006 025	Metal Washer
13	013N025	Pinion Gear
14	014 040	Dog Spring (2 req.)
15	015N025	Dog (2 req.)
18	018 040	Clutch Disc Spring (4 req.)
20	020 040	Thrust Washer
21	021R025	Cam Lever
21B	*021B40	Cam Lever Insert
23	023 006CH	Gear Mounting Screw
23A	023 114	Handle Screw
24	024 320	Handle
26	026N025	Ball Bearing Drive Plate
26A	026N025	L.S. Spool Bearing
28	028 025	L.S. Ring
29L	029LN025	Spool
32	032 022	Lower Plate Screw (2 req.)
33	033 113	Rod Clamp
	*033R200	Ringed Rod Clamp (Optional)
34	034 045	Clamp Screw (Only)
34C	034C045	Rod Clamp Screw w/Nuts
35	035 025	Click Tongue
36	036 025	Click Button
37	037 040	Post (2 req.)
38	038 040	R.S. Post Screw (2 req.)
39	039 001	R.S. Screw (Top)
39A	039 009	L.S. Post Screw (2 req.)
40D	040D025	Friction Washer
41	041 040	Pre-Set Knob Spring
41A	041 025	Bearing Spring
50	050 025	Gear Stud Cover
55	055 116	Spool Bearing (2 req.)
60	060 025	Lever Backing Washer
62	062 025	Click Spring
63	063 500S	Bridge Mounting Screw (2 req.)
63A	063 500S	Click Spring Screw
67	067 025	Ratchet Retaining Ring
69	069B050	Strike Button Retaining Ring
69A	069B050	Free Spool Button Retaining Ring
69B	069B600	Click Tongue Retaining Ring
71L	071L025	Spool Spindle Assembly
81	081 025	Click Ratchet
82	082 025	Handle Shim
83	083 025	Pre-set Collar
98	098 025	Main Gear Ratchet
110	110 050	R.S. Quadrant Ring Screw
110A	110 050	L.S. Stand Screw
110B	110 060	Handle Lock Screw
117	117 025	Drive Plate Assembly
134	134 025	Gear Stud
134A	*134A025	Gear Stud Washer
141	141 025	Cam Follower
144	144 025	Pre-Set Knob
149	149 045	Clamp Nut (2 req.)
149A	149 200	Hex Nuts (2 req.)
156	156 025	Drag Cover
161	161 025	Free Spool Button
161A	161 040	Strike Button Assembly
162	162 050	Free Spool Button Spring
162A	162 050	Strike Button Spring
183	183 025	Frame Assembly