


Zebco 33™

WWW.REELDR.COM



Key

Key No.	Part No.	Description
1	LZ24//SA	Front Cover Assembly
2	NZ10//SA	Spinner Head Assembly
3	LZ21//CP	Spool-order form attached
4	LZ23//SA	Back Cover Assembly
5	LZ7//SA	Brake Bar Assembly
6	JZ20/.2	Control Shaft Spring
8	LZ46//SA	Brake Ring Assembly
9	BZ3//TP	Crank Nut
10	LZ18//SA	Crank Handle Assembly
11	LZ55/T	Cover Lock Screw
13	LZ11//THT	Pinion Gear
14	LZ8//SA	Crank Shaft Gear
15	LZ29/1	Retainer Clip
16	LZ32//TMP	Adjustment Screw

Key

Key No.	Part No.	Description
19	BZ36//TP	Adjustment Nut
21	LZ35//TP	Cam Lever
22	LZ56//CP	Cover Lock
23	LZ1//SA	Body Assembly
26	BZ2//TP	Click Knob
27	LZ9//SA	Thumb Stop
29	LZ19-1/0	Pinion Gear Washer
30	LZ53//TP	Brake Ring
32	LZ40-1/0	Spool Latch Screw
33	LZ34/2	Spool Latch
34	LZ17//TP	Center Bushing
	QZ76/0	Click Spring Rivets
	LZ54/1	Nylon Washer