



Key No.	Part No.	Description
1	JS321	SPOOL ASSY.
7	GS315	CTR SHAFT ASSY.
8	GS048	BAIL SCREW B
10	GS347	BAIL ASSY
11	NB004	LINE ROLLER
12	FS016	LN/ROLLER/BUSH.
13	GS007	BAIL ARM A
14	GS051	BAIL SCREW A
15	FS102	BAIL AXLE WASH
16	FS108	BAIL AXLE SCREW
17	RB006	ROTOR NUT
19	RB022	BAIL SPR. PS20
20	JS087	BAIL SPRING COVER
21	FS085	BAIL TRIP LVR CVR
22	RB049	TRIP LVR. SPR.
23	RB019	TRIP LVR. PS20
24	RB037	TRIP LEVER SCREW
25	JS024	TRIP LVR. COVER
26	FS085	BAIL TRIP LVR CVR
27	JS009	ROTOR
28	NB080	BEARING RET. SCR.
29	RB040	BEARING RET.
30	FS028	BALL BEARING
31	FS011	PIN.GEAR 4110,20
32	JS301	BODY ASSY.
33	FS059	A/R LEVER
34	FS090	A/R LVR. SP.
36	NB080	BEARING RET. SCR.
39	FS081	PIN SLIDER

WWW.REELDR.COM

Key No.	Part No.	Description
40	FS068	CLICK CLAW
41	FS104	SLIDER HOLDER
42	FS046	DRAG WASHER C
44	FS030	DRAG WASHER A
45	VB039	DRAG WASHER B
46	VB071	DRAG WASHER D
47	VB031	DRAG COIL SPR
48	FS112	DRAG NUT
49	VB070	DRAG RET. RING
50	JS032	DRAG KNOB
51	FS079	DRAG SCREW
52	FS012	CRANK GEAR 4110-20
53	FS025	OSCILLATOR SLIDER
54	RB026	CRANK GEAR SHIM
56	FS063	A/R PAWL
57	FS089	A/R SCREW
58	JS323	SIDE PLATE ASSY.
59	FS057	SLIDE PLATE SCR.
60	FS073	HANDLE CAP
61	FS318	HANDLE ASSY
64	RB086	SLIDER SPRING
68	RB062	KICK LEVER PIN
76	FS035	DRAG WASHER E
78	FS105	HNDLE SCR. WASH
79	FS033	BACK CLAW
80	FS036	REAR DRAG WASH

Prices subject to change without notice. Prices do not include postage and handling. Some parts may not be available.

PLEASE ORDER BY PART NUMBER

Rev. 5/93

Zebco Division Brunswick Corporation, Box 270, Tulsa, OK 74101 USA 918-836-5581

