



# TEBCO 88 (w/External Bail Trip)



Key No.	Part No.	Description
1	RA301	Body w/ Label
2	RA323	Side Plate Assembly
3	RA057	Side Plate Screw
4	RA063	Anti-Reverse Pawl
5	RA069	Anti-Reverse Spring
6	RA059	Anti-Reverse Knob
7	RA031	Drag Washer (red)
8	RA038	Drag Sleeve
9	RA066	Drag Drive
10	RA039	Drag Washer (leather)
11	RA030	Keyed Drag Washer
12	RA043	Drag Spring
13	RA070	Drag Screw Spring
14	RA034	Drag Screw
15	RA032	Drag Knob
16	RA050	Drag Knob Retainer

Key No.	Part No.	Description
17	RA084	Crank Gear Shim
18	RA012	Crank Gear
19	RA318	Handle Assembly
20	RA068	Click Spring
21	RA080	Click Spring Screw
22	RA049	Ratchet Spring
24	RA009	Rotor Complete
25	RA024	Pinion Gear Washer
26	RA006	Rotor Retainer
27	RA025	Oscillator Slider
28	RA315	Center Shaft Assembly
29	RA078	Retainer Clip
30	RA047	Bail Arm Complete
31	RA321	Spool Complete

# TEBCO 88 (1985 Model with Internal Bail Trip)



[WWW.REELDR.COM](http://WWW.REELDR.COM)

Key No.	Part No.	Description
1	SA321	Spool Assembly
4	SA024	Pinion Gear Washer
5	SA315	Center Shaft Assembly
6	SA078	Retainer Clip
7	SA044	Oscillator Slider Lin
8	SA318	Handle Assembly
9	SA301	Body Assembly
10	SA006	Rotor Retainer
11	SA012	Crank Gear
12	SA063	Anti-Reverse Pawl
13	SA068	Click Spring
14	SA080	Click Spring Screw
15	SA043	Oscillator Slider
16	SA026	Crank Gear Shim
17	SA323	Side Plate Assembly
18	SA057	Side Plate Screw
19	SA054	Handle Retainer
20	SA069	Anti-Reverse Lock
21	SA059	Anti-Reverse Knob
22	SA031	Drag Washer (Red)
23	SA038	Drag Sleeve
24	SA066	Drag Drive
25	SA039	Drag Washer
26	SA030	Keyed Drag Washer
27	SA042	Drag Spring

Key No.	Part No.	Description
28	SA070	Drag Screw Spring
29	SA034	Drag Screw
30	SA032	Drag Knob
31	SA050	Drag Knob Retainer
32	SA008	Bail Screw
33	SA047	Bail Arm Assembly
34	SA045	Washer
35	SA008	Bail Screw
36	SA003	Bail Arm
37	SA102	Bail Axle Washer
38	SA007	Bail Axle Screw
39	SA085	Bail Cover Screw
40	SA023	Bail Trip Cover
41	SA019	Bail Trip Lever
42	SA049	Bail Trip Spring
43	SA009	Rotor Assembly
44	SA087	Bail Spring Cover
45	SA085	Bail Cover Screw
46	SA061	Anti-Reverse Pawl Spring
47	SA100	Anti-Reverse Pawl Screw
48	SA062	Release Lever
49	SA101	Release Screw
50	SA060	Release Spring
51	SA071	Brake Knob Click