


TEBCO Crossfire™ 10



Key No.	Part No.	Description
6	U0321	Spool Assembly
7	U0315	Center Shaft Assembly
9	U0051	Bail Screw A
10	U0051	Bail Screw B
11	U0108	Bail Axle Screw
12	U0048	Bail Axle Screw Washer
13	U0007	Bail Arm
15	U0016	Line Roller Bushing
16	U0004	Line Roller
18	U0347	Bail Assembly
20	U0006	Rotor Nut
21	U0309	Rotor
22	U0022	Bail Spring
23	U0025	Bail Spring Cover
24	U0024	Bail Trip Cover
25	U0085	Bail Cover Screw
26	U0019	Bail Trip Lever A
27	U0049	Bail Trip Spring
28	U0020	Bail Trip Lever B
30	U0111	Trip Lever Retainer
31	U0011	Pinion Gear
32	U0060	Anti-Reverse Ratchet
34	U0028	Pinion Bearing
35	U0040	Bearing Retainer
36	U0301	Body Assembly
37	U0054	Handle Retainer
38	U0071	Anti-Reverse Knob Retainer
39	U0069	Anti-Reverse Knob Spring

Key No.	Part No.	Description
40	U0059	Anti-Reverse Knob
41	U0081	Drag Click Spring Screw
42	U0068	Drag Click Spring
43	U0080	Anti-Reverse Pawl Screw
45	U0063	Anti-Reverse Pawl
46	U0026	Crank Gear Shim
47	U0012	Crank Gear
48	U0033	Drag Knob Click Spring
50	U0044	Oscillator Slider Link
51	U0009	Oscillator Retainer
52	U0100	Oscillator Slider Screw
53	U0109	Trip Lever Bushing
54	U0323	Side Plate Assembly
55	U0057	Side Plate Screw
60	U0318	Handle Assembly
63	U0110	Osc. Shaft Retainer (Screw)
64	U0038	Drag Sleeve
65	U0039	Drag Washer
66	U0066	Drag Drive
68	U0030	Keyed Drag Washer
71	U0031	Drag Spring
72	U0034	Drag Screw
73	U0070	Drag Screw Spring
74	U0032	Drag Knob
75	U0050	Drag Knob Retainer Screw
76	U0046	Oscillator Screw Bushing
77	U0013	Bail Axle
471	U0043	Oscillator Slider
472	U0027	Anti-Reverse Actuator

Key No.	Part No.	Description
6	V0321	Spool Assembly
7	V0315	Center Shaft Assembly
9	U0051	Bail Screw A
10	U0051	Bail Screw B
11	U0108	Bail Axle Screw
12	U0048	Bail Axle Screw Washer
13	V0007	Bail Arm
15	U0016	Line Roller Bushing
16	U0004	Line Roller
18	V0347	Bail Assembly
20	U0006	Rotor Nut
21	V0309	Rotor
22	U0022	Bail Spring
23	U0025	Bail Spring Cover
24	U0024	Bail Trip Cover
25	U0085	Bail Cover Screw
26	U0019	Bail Trip Lever A
27	U0049	Bail Trip Spring
28	V0020	Bail Trip Lever B
30	U0111	Trip Lever Retainer
31	V0011	Pinion Gear
32	U0060	Anti-Reverse Ratchet
34	U0028	Pinion Bearing
35	U0040	Bearing Retainer
36	V0301	Body Assembly
37	U0054	Handle Retainer
38	U0071	Anti-Reverse Knob Retainer
39	U0069	Anti-Reverse Knob Spring

Key No.	Part No.	Description
40	U0059	Anti-Reverse Knob
41	U0081	Drag Click Spring Screw
42	U0068	Drag Click Spring
43	U0080	Anti-Reverse Pawl Screw
45	V0063	Anti-Reverse Pawl
46	V0026	Crank Gear Shim
47	V0012	Crank Gear
48	U0033	Drag Knob Click Spring
50	U0044	Oscillator Slider Link
51	U0009	Oscillator Retainer
52	U0100	Oscillator Slider Screw
53	U0109	Trip Lever Bushing
54	V0323	Side Plate Assembly
55	U0057	Side Plate Screw
60	U0318	Handle Assembly
63	U0110	Osc. Shaft Retainer (Screw)
64	U0038	Drag Sleeve
65	U0039	Drag Washer
66	U0066	Drag Drive
68	U0030	Keyed Drag Washer
71	U0031	Drag Spring
72	U0034	Drag Screw
73	U0070	Drag Screw Spring
74	U0032	Drag Knob
75	U0050	Drag Knob Retainer Screw
76	U0046	Oscillator Screw Bushing
77	U0013	Bail Axle
471	V0043	Oscillator Slider
472	V0027	Anti-Reverse Actuator

TEBCO Crossfire™ 20

WWW.REELDR.COM

