


ZEBCO**GW4
DISCONTINUED**

Key No.	Part No.	Description
1	BL321	SPOOL ASSY. (1-8,13-15)
4	UK163	SPOOL RETAINER BUSHING
9	UK058	NUT RING SCREW
10	UK088	ROTOR NUT RING
11	UK006	ROTOR NUT
12	UK315	CENTER SHAFT
13	UK046	DRAG WASHER 'C'
14	UK039	DRAG WASHER 'B'
16	BL050	DRAG KNOB ASSY. (16-20)
21	BL009	ROTOR
22	UK022	ARM LEVER SPRING
23	UK087	ARM LEVER COVER
24	UK085	ARM LEVER COVER SCREW
25	UK048	BAIL HOLDER SCREW
26	UK345	BAIL HOLDER
27	UK346	BAIL WIRE
28	UK051	ARM LEVER SCREW
29	UK007	ARM LEVER
30	UK108	LINE SLIDER SCREW
31	UK017	LINE SLIDER COLLAR
32	UK004	LINE ROLLER
33	UK016	LINE ROLLER BUSHING
34	UK037	BAIL HOLDER COVER SCREW
35	UK024	BAIL HOLDER COVER
36	UK019	KICK LEVER
37	UK049	KICK LEVER SPRING
38	UK080	BEARING COVER SCREW
39	UK040	BEARING COVER
40	UK028	PINION BEARING

WWW.REELDR.COM

Key No.	Part No.	Description
41	UK060	STOPPER GEAR
42	UK126	PINION COLLAR
43	BL011	PINION
44	BL001	BODY
45	UK073	DUST COVER
47	UK059	ANTI-REVERSE SWITCH
48	BL157	BODY/SIDE PLATE BEARING
49	BL012	CRANK GEAR
50	UK026	CRANK GEAR WASHER
51	BL157	BODY/SIDE PLATE BEARING
52	BL023	SIDE PLATE
54	UK057	SIDE PLATE SCREW
55	BL318	HANDLE ASSY.
56	UK165	OSC. GUIDE WASHER
57	UK053	OSCILLATOR GEAR
58	UK025	OSCILLATOR GUIDE
59	UK084	CENTER SHAFT SCREW
60	UK014	STOPPER SUPPORT BUSHING
61	UK063	STOPPER
62	UK061	STOPPER SPRING
63	UK089	STOPPER SCREW
64	UK166	STOPPER SUPPORT
68	UK086	SLIDING SPRING
69	UK078	OSC. GEAR SCREW
70	UK167	OSC. GUIDE SUPPORT
71	UK168	OSC. SUPPORT SCREW
72	UK065	ROTOR RETAINER WASHER
73	BL109	PINION WASHER

Prices subject to change without notice. Prices do not include postage and handling. Some parts may not be available.

PLEASE ORDER BY PART NUMBER

Rev. 5/93

Zebco Division Brunswick Corporation, Box 270, Tulsa, OK 74101 USA 918-836-5581

BRUNSWICK