



Key No.	Part No.	Description
1	TL321	SPOOL ASSY.
2	TL315	MAIN SHAFT ASSY.
3	TL006	ROTOR NUT
4	TL065	ROTOR RETAINER WASHER
5	RL094	ROTOR NUT LOCK SCREW
6	TL009	ROTOR
7	RL085	COVER/CLICK CLAW SCREW
8	TL024	KICK LEVER COVER
9	TL019	KICK LEVER
10	RL037	KICK LEVER SCREW
11	TL049	KICK LEVER SPRING
12	TL031	SPRING SHAFT
13	TL022	BAIL SPRING
14	TL020	SPRING HOLDER
15	TL037	BAIL SPRING COVER
16	RL085	COVER/CLICK CLAW SCREW
17	RL034	E-CLIP
20	RL115	TRIP LEVER
21	TL347	BAIL ASSY.
22	TL004	LINE ROLLER
23	TL017	BAIL COLLAR
24	TL007	ARM LEVER
25	SL108	BAIL SCREW
27	TL051	BAIL HOLDER SCREW
28	TL080	BEARING PLATE SCREW
29	TL040	BEARING PLATE
30	TL028	BALL BEARING
31	TL060	RATCHET GEAR
32	TL011	PINION GEAR
33	TL001	BODY
34	RL091	STOPPER BUSHING
35	TL064	STOPPER 'A'

WWW.REELDR.COM

Key No.	Part No.	Description
36	TL063	STOPPER 'B'
37	TL061	STOPPER SPRING
38	RL083	STOPPER SCREW
39	TL033	DRAG CLICK CLAW
40	TL075	METAL
41	TL038	DRAG 'B' WASHER - 1
42	TL030	DRAG 'A' WASHER
43	TL039	DRAG 'B' WASHER - 2
44	TL066	DRAG 'D' WASHER
45	TL043	DRAG COIL SPRING
46	TL046	DRAG ADJUSTING WASHER
47	TL029	DRAG NUT
48	TL032	DRAG CAP
49	RL079	DRAG CAP SCREW
50	TL059	STOPPER LEVER
51	RL013	BODY/BODY COVER BUSHING
52	TL086	SILENT CAM
53	TL012	DRIVE GEAR
54	RL026	DRIVE GEAR ADJ. WASHER
55	RL013	BODY/BODY COVER BUSHING
56	TL053	O/S PLATE GEAR
58	TL081	O/S SLIDER
59	TL078	SLIDER STOPPER
60	TL161	SLIDER STOPPER SCREW
61	TL068	CLICK CLAW
62	RL085	COVER/CLICK CLAW SCREW
63	TL023	BODY COVER
64	SL057	BODY COVER SCREW
65	TL318	HANDLE ASSY.
66	SL076	HANDLE SCREW CAP WASHER
67	PL073	HANDLE SCREW CAP
68	TL082	KICK LEVER GUIDE

Prices subject to change without notice. Prices do not include postage and handling.

**PLEASE ORDER BY PART NUMBER**

Rev. 5/83

Zebco Division Brunswick Corporation, Box 270, Tulsa, OK 74101 USA 918-836-5581

