



Key No.	Part No.	Description	Key No.	Part No.	Description
1	BT321	SPOOL ASSY. -	38	BT059	ANTI-REVERSE LEVER
2	BT315	MAIN SHAFT ASSY	39	BT068	CLICK CLAW
5	BT048	BAIL HOLDER SCREW	40	BT067	CLICK CLAW SCREW
6	BT347	BAIL ARM ASSY.	41	BT104	SLIDER HOLDER
7	VB004	LINE ROLLER	42	BT030	REAR DRAG WASHER 'A'
8	VB016	LN ROLLER BUSHING	43	BT039	REAR DRAG WASHER 'B'
9	BT007	ARM LEVER	44	BT071	REAR DRAG WASHER 'D'
11	BT002	E-CLIP	45	BT066	CLICK GEAR
12	BT113	TRIGGER HOLDER	46	BT031	REAR DRAG COIL SPR.
13	BT111	ARM LEVER CAP	47	BT046	REAR DRAG ADJ. WSHR.
14	BT114	TRIGGER SPRING	48	BT112	REAR DRAG NUT
15	BT115	TRIGGER	49	BT017	SLIDING SCREW
16	BT116	TRIGGER PIN	50	BT033	BACK CLICK CLAW
17	VB102	BAIL AXLE WASHER	51	BT182	KICK LEVER GUIDE SCR
18	VB108	BAIL AXLE SCREW	53	BT132	REAR DRAG STOPPER
19	VB006	ROTOR NUT	56	BT032	REAR DRAG CAP
20	BT065	ROTOR RETAINER	57	VB079	DRAG SCREW
21	BT022	BAIL SPRINGS	58	BT013	BODY COVER BUSHING
22	BT087	BAIL SPRING COVER	59	BT014	A/R CLAW BUSHING
23	BT085	BAIL SPR. COVER SCREW	60	BT063	A/R CLAW (N)
24	BT049	KICK LEVER SCREW	61	BT064	A/R CLAW (S)
26	BT019	KICK LEVER	62	BT061	A/R CLAW SPRING
27	BT037	KICK LEVER SCREW	63	BT089	A/R CLAW SCREW
28	BT024	KICK LEVER COVER	66	BT081	PIN SLIDER
29	BT085	BAIL SPR. COVER SCREW	67	BT025	OSCILLATING SLIDER
30	BT009	ROTOR ASSY	70	BT012	DRIVE GEAR
31	BT080	BEARING PLATE SCREW	71	BT086	SLIDING SPRING
32	BT082	KICK LEVER GUIDE	72	RB026	CRANK GEAR SHIM
33	BT040	BEARING PLATE	73	BT323	BODY COVER ASSY.
34	RB028	BALL BEARING	74	BT057	BODY COVER SCREW
35	BT060	RATCHET GEAR	76	VB318	HANDLE ASSY
36	BT011	PINION GEAR	77	BT073	HANDLE SCREW CAP
37	BT301	BODY ASSY	79	BT120	ROTOR RET. SPRG. W/S

WWW.REELDR.COM

Prices subject to change without notice. Prices do not include postage and handling. Some parts may not be available.

PLEASE ORDER BY PART NUMBER

Rev. 5/93

Zebco Division Brunswick Corporation, Box 270, Tulsa, OK 74101 USA 918-836-5581

