



Key No.	Part No.	Description
1	ET321	SPOOL ASSY.
3	ET315	MAIN SHAFT ASSY.
4	DT044	BAIL HOLDER PIN
6	ET347	BAIL ARM ASSY.
7	NB004	LINE ROLLER
8	NB016	LINE ROLLER BUSH.
9	NB007	BAIL ARM A
10	ET043	ARM LEVER PIN
11	DT002	E-CLIP
17	NB102	BAIL AXLE WASHER
18	NB108	BAIL AXLE SCR
19	NB006	ROTOR NUT
20	DT065	ROTOR RETAINER
21	ET022	BAIL SPRING
22	ET087	BAIL SPRING COVER
23	BT085	BAIL SPR. COVER SCREW
24	DT049	KICK LEVER SPRING
25	DT058	KICK LEVER SPR. SCR.
26	ET019	KICK LEVER
27	ET037	KICK LEVER SCREW
28	ET024	KICK LEVER COVER
29	BT085	BAIL SPR. COVER SCREW
30	ET009	ROTOR ASSY.
31	BT080	BEARING PLATE SCREW
33	DT040	BEARING PLATE
34	NB028	BALL BEARING
35	NB060	A/R RATCHET
36	DT011	PINION GEAR
37	ET301	BODY ASSY.
38	DT059	ANTI-REVERSE LEVER
39	DT068	CLICK CLAW
40	BT067	CLICK CLAW SCREW

WWW.REELDR.COM

Key No.	Part No.	Description
41	DT104	SLIDER HOLDER
42	DT030	REAR DRAG WSHR. 'A'
43	DT039	REAR DRAG WSHR. 'B'
44	DT071	REAR DRAG WSHR. 'D'
46	DT031	REAR DRAG COIL SPR.
47	DT046	REAR DRAG ADJ. WSHR.
48	DT112	REAR DRAG NUT
49	DT017	SLIDING SCREW
50	DT033	BACK CLICK CLAW
53	DT132	REAR DRAG STOPPER
56	DT032	REAR DRAG CAP
57	DT079	REAR DRAG CAP SCREW
58	BT013	BODY COVER BUSHING
59	DT014	A/R CLAW BUSHING
60	DT063	A/R CLAW (N)
63	DT089	A/R CLAW SCREW
64	NB053	OSCILLATING GEAR
65	NB078	OSC. GEAR SCR.
67	NB025	OSCILLATOR SLIDER
68	NB083	STOPPER
69	NB084	STOPPER SCREW
70	NB012	CRANK GEAR
71	NB086	SLIDER SPRING
72	RB026	CRANK GEAR SHIM
73	ET323	BODY COVER ASSY.
74	DT057	BODY COVER SCREW
76	NB318	HANDLE ASSY.
77	CT073	HANDLE SCREW CAP

Prices subject to change without notice. Prices do not include postage and handling. Some parts may not be available.

PLEASE ORDER BY PART NUMBER

Rev. 5/93

Zebco Division Brunswick Corporation, Box 270, Tulsa, OK 74101 USA 918-836-5581

