


QUANTUM GW8



WWW.REELDR.COM

**KEY PART
NO. NO.**

KEY PART NO. NO.	DESCRIPTION
1 FL321	SPOOL ASSY. (1-8,13-15)
4 YK163	SPOOL RETAINER BUSHING
9 YK058	NUT RING SCREW
10 WK088	ROTOR NUT RING
11 YK006	ROTOR NUT
12 YK315	CENTER SHAFT
13 WK046	DRAG WASHER 'C'
14 WK039	DRAG WASHER 'B'
16 FLO50	DRAG KNOB ASSY. (16-20)
21 FLO09	ROTOR
22 YK022	ARM LEVER SPRING
23 YK087	ARM LEVER COVER
24 UK085	ARM LEVER COVER SCREW
25 YK048	BAIL HOLDER SCREW
26 YK345	BAIL HOLDER
27 YK346	BAIL WIRE
28 YK051	ARM LEVER SCREW
29 YK007	ARM LEVER
30 YK108	LINE SLIDER SCREW
31 YK017	LINE SLIDER COLLAR
32 YK004	LINE ROLLER
33 YK016	LINE ROLLER BUSHING
34 UK037	BAIL HOLDER COVER SCREW
35 YK024	BAIL HOLDER COVER
36 YK019	KICK LEVER
37 YK049	KICK LEVER SPRING
38 UK080	BEARING COVER SCREW
39 YK040	BEARING COVER
40 YK028	PINION BEARING

**KEY PART
NO. NO.**

KEY PART NO. NO.	DESCRIPTION
41 YK060	STOPPER GEAR
42 YK126	PINION COLLAR
43 FLO11	PINION
44 FLO01	BODY
45 YK073	DUST COVER
47 YK059	ANTI-REVERSE SWITCH
48 FL157	BODY/SIDE PLATE BEARING
49 FLO12	CRANK GEAR
50 WK026	CRANK GEAR WASHER
51 FL157	BODY/SIDE PLATE BEARING
52 FLO23	SIDE PLATE
54 WK057	SIDE PLATE SCREW
55 FL318	HANDLE ASSY.
56 YK165	OSC. GUIDE WASHER
57 YK053	OSCILLATOR GEAR
58 YK025	OSCILLATOR GUIDE
59 WK084	CENTER SHAFT SCREW
60 WK014	STOPPER SUPPORT BUSHING
61 YK063	STOPPER
62 YK061	STOPPER SPRING
63 YK089	STOPPER SCREW
64 YK166	STOPPER SUPPORT
68 WK086	SLIDING SPRING
69 YK078	OSC. GEAR SCREW
70 YK167	OSC. GUIDE SUPPORT
71 UK168	OSC. SUPPORT SCREW
72 YK065	ROTOR RETAINER WASHER

Prices subject to change without notice. Prices do not include postage and handling.

PLEASE ORDER BY PART NUMBER

Rev. 11/90

Zebco Division Brunswick Corporation, Box 270, Tulsa, OK 74101 USA 918-636-6581