



Key No.	Part No.	Description	Key No.	Part No.	Description
1	JL321	SPOOL ASSY.	38	CT059	ANTI-REVERSE LEVER
2	CT315	MAIN SHAFT	39	CT068	CLICK CLAW
4	CT051	BAIL HOLDER PIN	40	BT085	BAIL SPR. COVER SCREW
6	CT347	BAIL ARM ASSY.	41	CT104	SLIDER HOLDER
7	CT004	LINE ROLLER	42	CT030	REAR DRAG WSHR 'A'
8	CT017	SLIDING SCREW	43	CT039	REAR DRAG WASHER 'B'
9	CT007	ARM LEVER	44	CT045	REAR DRAG WASHER 'D'
11	CT034	E-CLIP	46	CT043	REAR DRAG COIL SPRING
12	CT113	TRIGGER HOLDER	47	CT046	REAR DRAG ADJ. WSHR.
13	BT111	ARM LEVER CAP	48	CT112	REAR DRAG NUT
14	BT114	TRIGGER SPRING	49	CT029	SLIDING SCREW
15	BT115	TRIGGER	50	CT033	BACK CLICK CLAW
16	BT116	TRIGGER PIN	51	BT085	BAIL SPR. COVER SCREW
17	CT102	BAIL AXLE WASHER	53	CT132	REAR DRAG STOPPER
18	CT108	BAIL AXLE SCREW	56	JL032	REAR DRAG CAP
19	CT006	ROTOR NUT	57	BT079	DRAG SCREW
20	CT065	ROTOR RETAINER	58	BT013	BODY COVER BUSHING
21	CT022	BAIL SPRING	59	BT014	A/R CLAW BUSHING
22	CT087	BAIL SPRING COVER	60	CT063	A/R CLAW (M)
23	BT085	BAIL SPR. COVER SCREW	61	CT064	A/R CLAW (S)
24	CT049	KICK LEVER SPRING	62	CT061	A/R CLAW SPRING
26	CT019	KICK LEVER	63	BT089	A/R CLAW SCREW
27	BT037	KICK LEVER SCREW	66	BT081	PIN SLIDER
28	CT024	KICK LEVER COVER	67	BT025	OSCILLATING SLIDER
29	BT085	BAIL SPR. COVER SCREW	70	CT012	DRIVE GEAR
30	JL009	ROTOR	71	BT086	SLIDING SPRING
31	BT080	BEARING PLATE SCREW	72	BT026	CRANK GEAR SHIM
32	CT082	KICK LEVER GUIDE	73	JL323	BODY COVER ASSY.
33	CT040	BEARING PLATE	74	BT057	BODY COVER SCREW
34	BT028	BALL BEARING	76	JL318	HANDLE ASSY.
35	BT060	RATCHET GEAR	77	CT073	HANDLE SCREW CAP
36	CT011	PINION GEAR	78	CT120	ROTOR RET. SPRG. W/S
37	JL301	BODY ASSY.			

WWW.REELDR.COM

Prices subject to change without notice. Prices do not include postage and handling. Some parts may not be available.

PLEASE ORDER BY PART NUMBER

Rev. 5/93

Zebco Division Brunswick Corporation, Box 270, Tulsa, OK 74101 USA 918-836-5581

