


QUANTUM SE1



Key No.	Part No.	Description
1	GU332	Drag Knob Ass'y
2	GU038	Drag Retainer
3	GU105-5	Spool Washer "B"
4	GU081	Spool Washer "A"
5	GU080	Spool Washer "D"
6	XU321	Spool Ass'y
7	GU105-6	Spool Adj. Washer
8	AQ068-1	Spool Click Gear
9	GU006	Rotor Nut
10	GU077-2	Kick Lever Cover Screw
11	GU046	Kick Lever Cover
12	GU019	Kick Lever
13	KQ049	Kick Lever Spring
14	GU077-4	Rotor Nut Lock Screw
15	KQ034	"E"-Clip
16	KQ034	"E"-Clip
17	KQ108	Bail Screw
18	XU067	Arm Lever
19	GU051-6	Arm Lever Pin
20	EQ017-1	Bail Collar
21	EQ004-1	Line Roller Bearing
22	MT016-2	Line Roller Bushing
23	XU347	Bail Ass'y
24	KQ031	Spring Shaft
25	KQ049-3	Arm Lever Spring
26	QL020	Spring Holder
27	GU087	Arm Lever Spring Cover
28	GU077-2	Arm Lever Spring Cover Screw
29	NL096	Trip Link Spring
30	GU097	Trip Link Ass'y

WWW.REELDR.COM

Key No.	Part No.	Description
31	GU115	Trip Lever Ass'y
32	AQ028	Bail Bearing
33	PL060	Ratchet Gear
34	GU011	Pinion Gear
35	GU077	Bearing Screw
36	GU073-2	Handle Screw Cap
37	GU105	Handle Cap Washer
38	GU001-3	Body
39	GU090	Stopper Lever
40	GU089	Stopper Lever Spring
41	GU091	Stopper Bushing
42	GU061	Stopper Spring
43	GU063	Stopper "A"
44	GU074	Stopper "B"
45	GU077-5	Stopper Screw
46	GU027	Body Bushing
47	GU012	Drive Gear
48	GU086	Silent Cam
49	GU105-8	Drive Gear Adj. Washer
50	GU027	Body Cover Bushing
51	GU053	Oscillation Gear
52	GU025	Oscillation Slider
53	GU100	Main Shaft Screw
54	GU023-3	Body Cover
55	GU057	Body Cover Screw
56	GU318-9	Handle Ass'y
57	GU015	Main Shaft
58	GU009-3	Rotor

Prices subject to change without notice. Prices do not include postage and handling.

PLEASE ORDER BY PART NUMBER

Rev. 5/93

Zebco Division Brunswick Corporation, Box 270, Tulsa, OK 74101 USA 918-836-5581

